

TRACKER USAGE GUIDE



This document is valid for both participants and organizers.
Follow these instructions to turn your tracker on and off correctly.

1 KNOW YOUR TRACKER

FRONTAL PART



- GPS (BLUE)
Position via satellite
- PWR (RED)
Power
- CEL (GREEN)
Mobile network connection

UPPER PART

ON/OFF BUTTON



ON/OFF BUTTON

Use it to **TURN ON OR OFF** the tracker
In both cases, the procedure
is the same.

2 TURN ON THE TRACKER

- 1** Press the power button firmly for **4-5 seconds**.
- 2** First, the red LED (PWR) is switched on permanently.
- 3** Right after that, only the blue (GPS) and green (CEL) LEDs will start to blink. The red (PWR) LED will go out.



3 TURN OFF THE TRACKER

- 1** Press the power button firmly for **4-5 seconds**.
- 2** The red LED (PWR) will start fixed and, together with the blue (GPS) and green (CEL) LEDs will start to blink.
- 3** Keep the button pressed until the three LEDs are turned off and the tracker shuts down completely.



4 IMPORTANT RECOMMENDATION



Like all GPS, it's important that your tracker have a view of the sky so that I can synchronize correctly and obtain the best accuracy of location.



Avoid covering the tracker with metallic objects or to remain in closed places for long periods.



If you have any questions, contact the event organizer.

CHECK YOUR TRACKER BEFORE STARTING THE RACE



CHECK IT WITH NFC

It is very important to make sure that your tracker is working properly before starting the race.

1 BRING YOUR PHONE CLOSE TO THE TRACKER




Activate NFC on your phone and bring it close to the back of the tracker (where the wave symbol is).

2 WAIT FOR THE TRACKER TO BE READ



Your phone will read the tracker and show basic information together with management options.

3 CHECK YOUR INFORMATION



Make sure all the information is correct: battery, tracker status, race information and your bib number.



ALL GOOD?

If all the information is correct, your tracker is ready for the race.

If you have any issue, contact the organization.



WHY DO YOU RECEIVE A TRACMOVE GPS TRACKER?

A safety, tracking and control tool that helps
make the event safer and better organized.

1

SAFETY



- It helps locate you more accurately if you need assistance.
- It helps the organization respond faster in the event of an incident.
- It is especially useful on long routes or in isolated areas.

2

RACE TRACKING



- It helps monitor participants' progress throughout the route.
- It helps validate checkpoints and route references.
- It complements sports tracking and race information.

3

BETTER COORDINATION



- It makes event logistics and operations easier to manage.
- It gives Race Office and the organization better visibility.
- It reduces uncertainty and improves decision-making.

4

YOUR COOPERATION



- Carry it correctly throughout the event.
- Take care of it and avoid impacts or interference.
- Return it at the finish line or at the point indicated by the organization.



**In short: the GPS tracker is not just a tracking device.
It is a tool that improves **safety**,
organization and **event control**.**

